

How To Replace Window Sashes For Sliding Windows



- 1** **Unlock the window.**
(Turn lock lever/levers to the top position)

Open the sash approximately 3 inches.
(Should be able to fit 3 fingers between the sash and frame)

2



- 3** **Grip both sides of the open sash firmly in the middle.**

Holding the sash, push it up into the head. (This will lift the bottom of the sash out of the track)

4



- 5** **With the sash lifted, angle the bottom part out of the track and frame. The sash will then slide right out.**

- 6** **To install sash again, reverse process.**