


# Replacement Parts For Window Sash and Screen

## Series 300 Molded Hopper Window

Call 888.504.0005 to Order Parts For American Craftsman® Windows

### Sash Parts

Interior View



**Right Handle**  
12-300-R-WHT




**Left Handle**  
12-300-L-WHT

**Screw**  
(order as many as needed)  
00-10121

Exterior View



**Bulb Seal**  
109-22-12102-WHT-6



**Bulb Seal**  
109-22-PP430-WHT-6




**Glazing Bead**  
109-52-317-WHT-8

### Screen Parts



**Screen Corner**  
200-807-021



**Screen Latch**  
200-079-042